

Cleaning your Smart TV Display

To clean your screen:

1. Turn off any connected computers.
2. Turn the display off.
3. Wipe all surfaces with a dry lint-free, non-abrasive cloth to remove dust and debris.
4. Gently spray a small amount of the water on a second cloth.
Note: *Do not oversaturate the cloth to the point it is dripping.*
5. Wipe the screen with the dampened cloth.
6. After wiping the screen, wipe off the remaining SMART Board surfaces that one can normally touch, such as the frame, pens, and other accessories.

If the screen requires sanitation, you may substitute one of the following:

Diluted bleach solution

To mix the correct solution, using standard household bleach at a strength of 5% Sodium Hypochlorite:

- 4 tsp. of bleach per quart of distilled water
- 1/3 Cup bleach per gallon of distilled water
- 20ml bleach per 980ml distilled water
- 80ml bleach per 3.92L distilled water

70-90% isopropyl alcohol

Isopropyl alcohol comes pre diluted and no mixing is required. For concentrations above 90%, dilute accordingly with distilled water.

We recommend using a spray bottle for applying the solution to the cloth to avoid oversaturating it.

Note: Test a small, inconspicuous area before you clean the entire surface.



Caution

- Do not use permanent or dry-erase markers on the screen. If dry-erase markers are used on the screen, remove the ink as soon as possible with a lint-free, non-abrasive cloth.
- Do not rub the screen with dense or rough material.
- Do not apply pressure to the screen.
- Do not use cleaning solutions, Clorox wipes or glass cleaners on the screen, because they can deteriorate or discolor the screen.